THE ABS COMPANY

CHANGING BUMPERS ON THE TIREFLIP 180 AND TIREFLIP 180 XL



Changing out a TireFlip 180/XL bumper is very easy. Start with a M6 Hex key and remove the 6 bolts around the base of the bumper. Once these have been removed, you can discard them and the damaged bumper.

Take a moment to inspect the locking nut for the top of the foot and make sure it is snug to the upper base. If not, tighten it now while you have the bumper off.

Next set the bumper down on top of the mounting base and then place the mounting ring over the bumper. Next attach the bumper to the base using the three new bolts provided in the bumper kit. Once you have secured the ring around the base of the bumper you are done and ready to use the unit once again!

If there are questions during an install for a tech, PLEASE do not hesitate to call us and discuss! We are happy to assist and make sure that every install goes smoothly. We are happy to hop on FaceTime or Zoom and video chat to make sure things are set up correctly. Just call 866-219-5335 Option 5 and we can set up a video conference.

Call for details: **1-866-219-5335** Outside the US: **1-908-879-2713**